



Product Installation Instructions

Door Sweep

To complete installation, you will need:

- Self-stick vinyl door sweep (included in your kit)
- Measuring tape
- Scissors

Instructions

1. Make sure the door surface is clean, dry and grease-free.
2. Measure door width.
3. Shorten sweep if needed.
4. Place the product so the sweep flexes against the threshold.
5. Remove the backing and press into place.

